

# Metal Plumbers Tape Installation

## Tools & Materials Needed:

- Metal plumber's tape (steel or galvanized)
- Screws or bolts (appropriate for the mounting surface)
- Drill or screwdriver
- Tape measure
- Tin snips or heavy-duty scissors
- Pencil or marker
- Safety gloves and goggles



## Step-by-Step Installation:

### 1. Measure and Cut the Tape

- Determine the length of the metal plumber's tape needed by measuring the pipe or fixture you are securing.
- Use tin snips or heavy-duty scissors to cut the tape to the required length.
- Smooth any sharp edges to prevent injuries during handling.

### 2. Position the Tape

- Wrap the cut piece around the pipe, duct, or fixture, ensuring a secure fit.
- Align the perforations with the mounting surface to allow for easy fastening.
- Leave a slight gap for adjustments if necessary.

### 3. Secure the Tape

- Insert a screw or bolt through one of the perforations.
- Use a drill or screwdriver to fasten the tape to the surface securely.
- Repeat on the opposite side or at multiple points as needed for stability.
- Double-check that the tape holds the pipe or fixture firmly in place.

#### 4. Final Adjustments

- Ensure that the tape is not overly tight to allow for minor movement if necessary.
- Trim any excess tape if it extends too far beyond the secured area.
- Inspect the installation for stability and adjust as needed.

#### Safety Tips:

- Always wear safety gloves to avoid cuts from sharp metal edges.
- Use proper screws or bolts for the specific material of your mounting surface.
- Avoid overtightening to prevent damage to pipes or fixtures.
- Ensure secure fastening to prevent accidental loosening over time.



© 2025 Dundee Manufacturing Company. All rights reserved.

This document is the property of Dundee Manufacturing Company and may not be reproduced, distributed, or modified without written permission. Specifications are subject to change without notice.

For inquiries, contact:

Dundee Manufacturing Company

[www.dundeemfg.com](http://www.dundeemfg.com)